

Valves

Truck Valves



2512
Truck Valve
Flare to Male Pipe

| PART # | TUBE THREAD | PIPE THREAD |
|-----------|-------------|-------------|
| 2512x10x8 | 5/8 | 1/2 |



2517
Truck Valve
Hose Barb
to Male Pipe
Pin Handle

| PART # | HOSE ID | PIPE THREAD |
|-----------|---------|-------------|
| 2517x10x6 | 5/8 | 3/8 |



2513
Truck Valve
Flare to Male Pipe

| PART # | TUBE THREAD | PIPE THREAD |
|-----------|-------------|-------------|
| 2513x8x6 | 1/2 | 3/8 |
| 2513x8x8 | 1/2 | 1/2 |
| 2513x10x8 | 5/8 | 1/2 |
| 2513x12x8 | 3/4 | 1/2 |



2518
Truck Valve
Hose Barb to
Male Pipe

| PART # | HOSE ID | PIPE THREAD |
|-----------|---------|-------------|
| 2518x10x8 | 5/8 | 1/2 |
| 2518x12x6 | 3/4 | 3/8 |
| 2518x12x8 | 3/4 | 1/2 |



2514
Truck Valve
Tube to Male Pipe

| PART # | NYLON TUBE THREAD | PIPE THREAD |
|----------|-------------------|-------------|
| 2514x8x8 | 1/2 | 1/2 |



2519
Truck Valve
Female Pipe to
Male Pipe

| PART # | FEMALE PIPE | MALE PIPE |
|----------|-------------|-----------|
| 2519x6x6 | 3/8 | 3/8 |
| 2519x6x8 | 3/8 | 1/2 |
| 2519x8x8 | 1/2 | 1/2 |



2515
Truck Valve
Tube to Male Pipe

| PART # | NYLON TUBE THREAD | PIPE THREAD |
|----------|-------------------|-------------|
| 2515x8x8 | 1/2 | 1/2 |



2521
Drain Cock

| PART # | PIPE THREAD |
|--------|-------------|
| 2521x4 | 1/4 |



2516
Truck Valve
Hose Barb to
Male Pipe

| PART # | HOSE ID | PIPE THREAD |
|-----------|---------|-------------|
| 2516x6x6 | 3/8 | 3/8 |
| 2516x10x6 | 5/8 | 3/8 |



2522
Truck Air Tank
Drain Valve
150PSI

| PART # | PIPE THREAD | CABLE LENGTH |
|-----------|-------------|--------------|
| 2522x4-7 | 1/4 | 7" |
| 2522x4-18 | 1/4 | 18" |
| 2522x4-24 | 1/4 | 24" |
| 2522x4-32 | 1/4 | 32" |
| 2522x4-36 | 1/4 | 36" |
| 2522x4-60 | 1/4 | 60" |